

mw Player

User Guide

Issue 1.0
29/6/2017

This software utility has the sole function of playing and (optionally) extracting portions of recordings made with mindwalker meters and saving them to a separate file. The program is very straightforward and intuitive to use.

Note that if audio is used in the recording, the file must be .wav format. Extraction cannot be done on any other format (MP3 etc). *Switch Sound File Converter* is a useful tool for converting audio files to different file formats and is available as a free version. (<http://www.nch.com.au/switch/>)

It is assumed that the user is familiar with other mindwalker software, particularly the recording and playback function.

Install the mw Player program in the usual way by unzipping the download and running setup.exe

Settings can be changed and saved by the same method as in the mw Classic software.

Load the required file for editing.

Click **PLAY** and the **START** button will be enabled.

Click the **START** button (or the keyboard space bar) to set the start point for the extraction and the **END** button becomes enabled.

Click the **END** button (or the keyboard space bar) to set the end point for the extraction and the **EXTRACT** button becomes enabled.

Click the **EXTRACT** button (or the keyboard “E”) to save the extracted clip to a file – you will be prompted for a file name.

To start the cycle anew press **PLAY** again, or first **LOAD** a different file.

All extracted portions are saved in the standard mw file format, so you could open the extracted file again and perform a further extraction on it if desired.